

# **PART NO: ABSHS-02**

## **06-10 DODGE CHARGER HOOD SCOOP**

**PLEASE READ THESE INSTRUCTIONS CAREFULLY PRIOR TO INSTALLATION**

**Important Note: Please inspect your hood scoop for proper fit before painting or mounting  
You may install the hood scoop with or without drilling.**

### **Installation Instructions**

#### **Hardware Kit (Supplied on each hood scoop)**

1. Locator = 1 pc                      2. Washers = 2 pcs                      3. Screws = 2 pcs

#### **Tools Required :-**

- Isopropyl alcohol or equivalent / Phillips Screwdriver / Masking Tape / Vacuum Cleaner / Centre Punch / Hand Drill / Drill Bits : 3/16" and 5/16" / Hammer

This Dodge Charger hood scoop kit is made from high quality ABS plastic. This product is produced by blow molding process with grille produced by high pressure injection.

#### **Hood Scoop Installation :-**

##### **Step 1**

1. Clean surface area that is to be covered by the hood scoop with isopropyl alcohol or equivalent.

##### **Step 2**

2. Remove the trim underneath the hood. Note :- Set the trim aside as it is to be re-attached to the vehicle after the installation of the hood scoop

##### **Step 3**

3. Peel the tape backing of the locator strip and attach it to the mounting holes of the hood scoop (illustration 1)

##### **Step 4**

4. Set the hood scoop on the center line of the hood and at a position where you get the best fit.

##### **Step 5**

5. Tape the locator strips on the hood, carefully remove the hood scoop leaving the locator strips. (illustration 2)

##### **Step 6**

6. Center punch the holes for drilling. Drill 3/16" holes on the two punch mark locations. Enlarge the holes using 5/16" drill. Use minimum pressure when drilling to avoid denting of hood

##### **Step 7**

7. Peel the tape backing at the corner (illustration 3) and tighten the two screws.

##### **Step 8**

8. Peel the tape backing completely and press the hood scoop gently onto the hood.

##### **Step 9**

9. Peel the tape backing of the grill and install it into grill cavity of the hood scoop. (illustration 4)

##### **Step 10**

10. Hood scoop with grill installed. (illustration 5)

*\*Refer to illustrations on next page*

# PART NO: ABSHS-02

## 06-10 DODGE CHARGER HOOD SCOOP

PLEASE READ THESE INSTRUCTIONS CAREFULLY PRIOR TO INSTALLATION

**Important Note:** Please inspect your hood scoop for proper fit before painting or mounting  
You may install the hood scoop with or without drilling.

### Illustrations

1)



4)



2)



5)



3)

